


43B 42 43D


COUNTY IN TOUCH


FIG. 3


SWITCH A	SWITCH B	SWITCH C	SWITCH D	LIGHT EMISSION	PEN DOWN	PEN BUTTON
×	×	1	l	OFF	OFF	OFF
0	×	×	×	NO	OFF	OFF
0	×	0	.×-	ON	ON	OFF
0	×	×	0	NO	OFF	NO
0	×	0	0	NO.	NO	NO
0	0	l °	1	NO	ON	NO
×	0	ı	1	NO	NO	OFF













)





F1 G. 10





FIG. 11







FIG. 13









FIG. 15






FIG. 17

